



Cable connection Thermozyklus Example wireless version on radiators



Press 2 buttons at same time to get :
A : Wireless RF address
Then O et U : ZE system address (**2789**)
O : thousands and hundreds, U tens and units.



*SF address : see address SF menu

** System address is the serial number of ZE (check under ZE).

	Bezeichnung: Wireless cable connection / SF	
	Name: Wireless cable connection / SF	
	Indication:	
	Maßstab: Unité:	Einheit: Unité:
Scale: Unité:	Unité: Unité:	erstellt am: 10th june 2009 NF/FS
Echelle:	Baugruppe: Assemblée:	Produit à:
Abmessung: Dimension:	Assemblée: Bloc:	geprüft am: Examiné à:
Dimension:	Bloc:	Examiné à: