



## Cable connection Thermozyklus Dual version : Wireless sensor RF, wireless actuator SF, switcher ST



Press 2 buttons at same time to get :  
*A* : Wireless RF address  
*O* et *U* : ZE address system (**2789**)  
 Then (*O* : for thousands and hundreds, *U* for tens and units).



**\*\*System address is the serial number of ZE (check under ZE).**

	Bezeichnung: Name: Indication:		<b>Wireless cable connection / ST / SF</b>	
	Maßstab: Scale: Echelle:	Einheit: Unity: Unité:	erstellt am: Provided in: Produit à:	
	Abmessung: Dimension: Dimension:	Baugruppe: Assembly: Bloc:	10th june 2009/NF/FS geprüft am: Checked in: Examiné à:	